



CADILLAC RV™

12 Pin Flat Plug Wiring Diagram

POWER UP YOUR CARAVAN THE RIGHT WAY



Wiring Diagram

When you're heading off on your next adventure, a reliable wiring setup is essential to keep everything in your caravan running smoothly and safely. A 12-pin wiring system goes beyond the basics to manage the outside running lights

With a 12-pin setup, you not only cover the essentials like brake lights, indicators, and power to your caravan, but you also unlock the ability to run on-road charging for your caravan batteries.

In simple terms, it's about making sure your caravan feels just as comfortable and functional on the road as it does when you've set up camp. A clear wiring diagram helps you understand how everything connects, giving you peace of mind that your gear will work the way it should – leaving you free to focus on the journey ahead.





Pin	Description	Wire Colour
1	Left Indicator	Yellow
2	Reverse	Black
3	Earth	White
4	Right Indicator	Green
5	Electric Brakes	Blue
6	Stop Lamps	Red
7	Marker Lights & Safety Dave Camera	Brown
8	3- Way Fridge Positive**	Red
9	Fridge Signal**	6mm Pink
10	Fridge Negative**	6mm White
11	Empty	Empty
12	Power from Vehicle	Purple

** These pins are to be Wired only if your van has a 3 Way Fridge. Consult your Sales Team member to confirm

Note: Standard Grey Anderson Plug Also Required – Charging of Caravan Battery Only



CADILLAC RV™

Contact

 2 Constance Court, Epping VIC 3076

 03 9133 3379

 cadillacrv.com.au

 contact@cadillacrv.com.au

